

SPARE PARTS LIST

Parts list for Mk3 RS1000 Perforated Drum Models- SS30 901 01

ITEM	PART NO.	DESCRIPTION	QTY	
C1	SS10 140 01	Pivot Bush - 19 diameter x 13 hole	5	
C2	SS10 140 08	Extension Chute Support inner	2	
C3	SS10 140 09	Extension Chute Support Outer	2	
C4	SS10 220 01	Cable Tray	1	
C5	SS15 022 01	Adjuster Stud - bearing Support	4	
C6	SS15 022 08	Inlet Hopper Baffle	1	
C7	SS15 141 04	Discharge Chute tensioner handle	2	Check B21, B22, B24
C8	SS30 015 00	End Plate- RH	1	
C9	SS30 016 00	End Plate – LH	1	
C10	SS30 017 01	Side infill plate	2	
C11	SS30 017 02	Upper infill plate	2	
C12	SS30 017 03	Rear strut bracket – RH	1	
C13	SS30 017 04	Rear strut bracket – LH	1	
C14	SS30 017 05	Outer roller scraper mount plate	2	
C15	SS30 022 01	Bearing support lower seal	2	P4&5 NOT Supplied
C16	SS30 023 01	Bearing support adjuster bracket- rear	2	
C17	SS30 023 02	Bearing Support adjuster bracket - front LH	1	
C18	SS30 023 03	Bearing support adjuster bracket- front RH	1	
C19	SS30 024 00	Lever arm pivot mount	2	
C20	SS30 025 03	Lever arm pivot bush	2	
C21	SS30 025 04	Lever arm pivot retaining washer	2	
C22	SS30 026 01	Outer roller bogie	2	
C23	SS30 026 02	Outer roller bogie bush	2	
C24	SS30 028 00	Lever arm assembly	2	
C25	SS30 030 01	Roller tension adjustment stud	2	
C26	SS30 030 02	Roller tension spring base nut	2	
C27	SS30 031 00	Roller tension tube	2	
C28	SS30 120 01	Inlet hopper end seal- plastic	2	
C29	SS30 120 02	Inlet hopper end seal clamp plate	2	
C30	SS30 204 01	Inlet hopper lid pivot bush	4	
C31	SS30 207 00	Chain side cover (RH)	1	
C32	SS30 208 00	Motor side cover (LH)	1	
C33	SS30 211 00	Side cover catch	2	
C34	SS30 214 00	Lower side cover complete	2	
C35	SS30 217 01	Inlet pipe backing flange	1	
C36	SS30 218 00	Outlet stub pipe - 160 diameter	1	
C37	SS30 219 01	Outlet blanking plate- 160 diameter	1	
C38	SS30 220 00	Outlet stub pipe- 110 diameter	1	
C39	SS30 221 01	Outlet blanking plate - 110 diameter	3	
C40	SS30 230 02	Washdown feed pipe	1	
C44	SS30 150 04	Inner roller seal clamping washer	8	
C45	SS30 209 01	Side guard infill	2	
B1	RL0017	110 mm Diameter End Cap	1	
B2	4008	Washdown Nozzle	3	
B3	OO5063	110 Diameter joining socket	1	
B4	OO7010	Washdown solenoid valve	1	
B5	OO7028	Wash down ball valve	1	

B6	OO4033	Washdown drain tap	1	
B7	101447	Roller tension adjustment nut - M16 brass	4	
B8	103582	Side covers gas strut only	4	
B9	103583	Side cover gas strut end loop	4	
B10	103584	Side cover gas strut fork	4	
B11	103585	Side cover gas strut fork clip	4	
B12	103630	Side cover catch	2	
B13	103631	Side cover pull tab	2	
B14	103632	Inlet hopper lid catch housing	2	Check items B15, B16
B15	103633	Inlet hopper lid catch drive stud	2	Check items B14, B16
B16	103634	Inlet hopper lid catch pawl	2	Check items B14, B15
B17	103635	Inlet hopper lid handle	1	
B18	10636	Side cover hinge	4	
B19	103793	Side cover finger pull	4	
B20	2367	Outer roller scraper spring	2	
B21	2375	Discharge Chute spring	2	
B22	2377	Discharge chute locking pin	2	
B23	5013	8mm 'T' handle (door catch)	1	
B24	6020	D' Shackle	4	
B25	6021	R' Clip	2	
B26	102179	Roll ring chain tensioner	1	
B27	1204	Transfer drive sprocket (61/19 type)	2	
B28	1266	Transfer drive chain (61 type)		69 links (51 3/4, 1315mm)
B29	1267	Transfer drive connecting link (61 type)		
B30	103646	Inner roller shaft seal packing		220mm per seal, trim to
P1	EL01 045 02	Gearbox retaining washer	1	
P2	EL01 045 04	Counterweight retaining washer	1	
P3	SS15 126 01	Drum alignment rollers	2	
P4	SS30 020 00	Bearing support- LH	1	
P5	SS30 021 00	Bearing support-RH	1	
P6	SS30 025 01	Drive anchor bracket	1	
P7	SS30 025 02	Drive restraint plate	1	
P8	SS30 105 03	Counterweight	1	
P9	SS30 122 00	Drum alignment roller bracket - LH	1	
P10	SS30 123 00	Drum alignment roller bracket - RH	1	
P11	SS30 132 01	Inner collection hopper end infill	2	
P12	SS30 132 02	Inner collection hopper end seal (rubber)	2	
P13	SS30 132 03	Inner collection hopper end seal clamp	2	
P14	SS30 216 00	Upper side cover complete	2	
PB1	1666	Drive key (10x8x100)	1	
S3	SS15 140 02	Discharge chute tray	1	
S4	SS15141 00	Discharge chute mount	1	
S5	SS30 018 00	Front tie bar	1	
S6	SS30 019 00	Rear tie bar	1	
S7	SS30 120 03	Inlet hopper lower seal -rubber	1	
S8	SS30 120 04	Inlet hopper lower seal clamp strip	1	
S9	SS30 121 00	Inlet hopper welded assembly	1	
S10	SS30 135 00	Overflow hopper welded assembly	1	
S11	SS30 145 00	Outer roller scraper	1	
S12	SS30 205 00	Inlet hopper lid	1	
S13	SS30 206 01	Top cover	1	

S14	SS30 230 01	Washdown spray tube	1	
SB1	0864A	Transfer drive sprocket taperlock bush	2	
SB2	103637	Outer roller bearing	4	
SP1	SS10 140 03	Discharge chute scraper (steel- optional)	1	Refer to carier
SP2	SS30 032 01	Roller tension spring spacer	2	Information Required
SP3	SS30 130 01	Inner collection hopper seal clamp plate	1	
SP4	SS30 130 02	Inner collection hopper seal (rubber)	1	
SP5	SS30 131 00	Inner collection hopper welder assembly	1	
SP6	SS30 150 01	Inner roller shaft seal mount	4	
SP7	SS30 150 02	Inner roller shaft seal spacer disc	4	
SP8	SS30 150 03	Inner roller shaft seal clamp disc	4	
SPB1	103645	Outer roller tension spring	4	
SPB2	103760	Inner roller	2	Complete with shaft
SPB3	103762	Outer roller- driven	1	Complete with shaft
SPB4	103765	Outer roller - driver	1	Complete with shaft
SPB5	1405M	Inner roller bearing	4	
SPB6	1661	Transfer drive sprocket key (14x9x60)	2	
SPB7	2378	Discharge chute scraper(plastic)	1	